


Please be aware this quick-start guide is not intended to be a substitute for the User Manual. To become familiar with all the operating procedures and technical information, be sure to read all information shown during the installation process.

1

 <https://info.alfa.com.tw/tube-uac2>

Please go to <https://info.alfa.com.tw/tube-uac2> to download the latest driver.


2



Setup.exe


After downloading double-click to install and follow the instructions.

3




Read the license agreement, choose **"I accept the terms of the license agreement"** and click **"Next"**.

4




Choose **"Install driver and Mediatek WLAN Utility"** and click **"Next"**.

5




Click **"Install"** to continue.

6




Click **"Finish"**.

7




Plug the Tube-UAC2 into your PC/ laptop.

8




Found New Hardware pops up from the utility bar.

9




Select your target network and double-click it.

10



Click **"Next"** then enter the network security key.

11



You should see a  symbol in front of the name of the network; It means you have successfully connected to your wireless network.

For more information, including macOS, Linux support, go to the URL below or scan the code:



<https://info.alfa.com.tw/tube-uac2>



This product is suitable for use in all EU countries.
© ALFA Network Inc.

Por favor, tenga en cuenta que esta guía de instalación rápida no es un sustituto del Manual de Usuario. Para familiarizarse con todos los procedimientos e información técnica, asegúrese de leer toda la información mostrada durante el proceso de instalación

1

<https://info.alfa.com.tw/tube-uac2>


Por favor, vaya a <https://info.alfa.com.tw/tube-uac2> para descargar el programa más reciente.

2




Después de descargarlo, haga doble clic para instalar y siga las instrucciones.

3




Leer el acuerdo de licencia, elija la opción “I accept the terms of the license agreement” (Acepto los términos del acuerdo de licencia) y seleccione “Next”.

4




Seleccione “Install driver and Mediatek WLAN Utility” (Instalar el driver y la utilidad WLAN de Mediatek) seleccione “Next”.

5




Seleccione “Install” para continuar.

6




Seleccione “Finish”.

7




Conecte el Tube-UAC2 a su PC/ Computadora Portátil.

8




En la barra de estado encuentre “Found New Hardware”.

9




Seleccione la red que desea conectarse y haga dos clic para conectarse.

10



Seleccione “Next”, y escribir el código de seguridad de la red.

11



Observara un pequeño ✓ símbolo en frente del nombre de la red, esto significa que está conectado exitosamente a la red inalámbrica.

Para obtener más información, sobre la compatibilidad con macOS, Linux, vaya a la siguiente URL o escanear el código:



<https://info.alfa.com.tw/tube-uac2>



Este producto es adecuado para todos los países de la EU.
ALFA Network Inc.® protegido por derechos del autor